This Exploded Drawing is for Informational Purposes Only. No Technical Support or Installation Instructions are Available.

If you do not see the part you are looking for on our website, please email partsrequest@smallappliance.com for assistance.

TOASTRONIC BASIC

This Exploded Drawing is for Informational Purposes Only. No Technical Support or Installation Instructions are Available.

If you do not see the part you are looking for on our website, please email partsrequest@smallappliance.com for assistance.

KRUPS TOASTRONIC BASIC

TYPE: 117

REFERENCE #	PART #	DESCRIPTION
1	4861143	CONTROL BUTTON
2	5810926	ELEMENT 120V
3	069277E	SPRING CONNECTING ROD
5	5861121	CRUMB TRAY
8	061140E	MAINS LEAD USA
9	5861246	BODY
10	4861189	ADAPTOR
11	4811334	CONTROL SLIDE
12	069275E	GRILL CLOSURE SPRING
13	4885754	AXLE
14	5873911	PCB 120V
18	4861159	PCB SUPPORT
19	4861186	KNOB DRIVE
20	4861184	THERMOSTAT CONTROL KNOB
21	069258E	OPENING GRILL SPRING
22	4861161	BASE
23	069840E	FOOT