
This Exploded Drawing is for Informational Purposes Only. No Technical Support or Installation Instructions are Available.

If you do not see the part you are looking for on our website, please email partsrequest@smallappliance.com for assistance.



This Exploded Drawing is for Informational Purposes Only. No Technical Support or Installation Instructions are Available.

If you do not see the part you are looking for on our website, please email partsrequest@smallappliance.com for assistance.

TYPE: 341

KRUPS CANYON DELUXE

REFERENCE#	PART#	DESCRIPTION
2	0907949	GRILL
3	0906198	ELEMENT
4	0906192	COVER (LEFT)
5	0906193	HANDLE (LEFT)
6	0907957	DRIP TRAY
7	0906197	CORD CLAMP
8	0906190	SWITCH SUPPORT
9	0906195	PUSHER
10	0906189	SWITCH
11	0906187	THERMOSTAT
12	0906194	COVER (RIGHT)
13	061181E	POWER CORD
14	0906191	ON/OFF SWITCH
15	0906196	HANDLE (RIGHT)
16	0906188	THERMOSTAT KNOB
17	0907956	FOOT