
This Exploded Drawing is for Informational Purposes Only. No Technical Support or Installation Instructions are Available.

If you do not see the part you are looking for on our website, please email partsrequest@smallappliance.com for assistance.

HAND MIXER

KitchenAid.






No.	No.	DESCRIPTION
1	9702835	Cover, Screw
2	9702826	Cord and Plug
4	9702827	Assembly Switch, Off/On Control (7 & 9 Speed)
5		Trim Band (Black)
6	9702817	Screw
7	2702808	Spring, Ejector

Following Parts Not Illustrated

### LITERATURE PARTS

F11. 40

Use and Care Guide Use and Care Guide
LIT9702920 KHM3 (3 Speed)
LIT9702921 KHM5TB (5 Speed)
LIT9702928 KHM5DH (5 Speed)
LIT9702918 KHM7 (7 Speed)
LIT9702919 KHM9 (9 Speed)
LIT4176951 Repair Parts List



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

6/97 Litho in U.S.A. (rle)

Part No. 4176951

# KitchenAid® 9-SPEED HAND MIXER

### MODELS:

KHM9PWH5 (White)

KHM900PK5 (Pink)

KHM900ER5 (Empire Red)

KHM9QWH5 (White)

KHM9QBU5 (Cobalt Blue)

KHM9QER5 (Empire Red)

KHM9QOB5 (Onyx Black)

KHM9QAC5 (Almond Creme)

KHM9QGN5 (Empire Green)

KHM9QMY5 (Majestic Yellow)




FOR CUSTOMER SATISFACTION ALWAYS USE FACTORY SPECIFICATION PARTS



**KITCHENAID** 

UNIT PARTS
Variations of Models: KHM7\_ \_5, 4KHM7\_ \_5



Illus. No.	Part No.	DESCRIPTION
1		Literature
	8212345	Use & Care Guide
_	8212055	(Trilingual) Repair Parts List
2	•	Mixer, Complete
3	8212348	Beaters, Turbo (Incl. Rt & Lt)

### ♦ Note:

Parts not sold separately. Must be purchased as a complete unit,

### **OPTIONAL PARTS** NOT ILLUSTRATED

8212351 Hooks, Dough (Incl. Rt & Lt) 8212341 Rod, Blending 8212340 Whisk

# KitchenAid® 7-SPEED HAND MIXER

### **MODELS:**

KHM7TWH5 (White)
KHM7TAC5 (Almond Creme)
KHM7TBU5 (Cobalt Blue)
KHM7TER5 (Empire Red)
KHM7TOB5 (Onyx Black)
KHM7TPK5 (Pink)
4KHM7TWH5 (White)
4KHM7TBU5 (Cobalt Blue)
4KHM7TER5 (Empire Red)
4KHM7TER5 (Empire Red)
4KHM7TAC5 (Almond Creme)
4KHM7TGN5 (Empire Green)
4KHM7TMY5 (Majestic Yellow)




FOR CUSTOMER SATISFACTION ALWAYS USE FACTORY SPECIFICATION PARTS



KITCHENAID

## **UNIT PARTS**

Variations of Models: KHM5\_ \_5,6,7, 4KHM5\_ \_5



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

## KitchenAid® 5-SPEED HAND MIXER

### **MODELS:**

KHM5TBWH5 (White)

KHM5DHWH5 (White)

KHM5APWH5 (White)

KHM5APOB5 (Onyx Black)

KHM5APER5 (Empire Red)

KHM5APBU5 (Cobalt Blue)

KHM5QWH5 (White)

KHM5QOB5 (Onyx Black)

KHM5QER5 (Empire Red)

KHM5QBU5 (Cobalt Blue)

KHM5APWH6 (White)

KHM5APOB6 (Onyx Black)

KHM5APER6 (Empire Red)

KHM5APBU6 (Cobalt Blue)

KHM5APWH7 (White)

KHM5APOB7 (Onyx Black)

KHM5APER7 (Empire Red)

KHM5APBU7 (Cobalt Blue)

4KHM5TBWH5 (White)

4KHM5DHWH5 (White)




FOR CUSTOMER SATISFACTION ALWAYS USE FACTORY SPECIFICATION PARTS



KITCHENAID

UNIT PARTS
Variations of Models: KHM3\_\_5, 4KHM3\_\_5



Illus. No.	Part No.	DESCRIPTION
1		Literature
•	8212344	Use & Care Guide
		(Trilingual)
_	8212053	Repair Parts List
2	0040040	Knob, Speed Cntrl
3		Gloss Grey Nimbus Mixer, Complete
4		Beaters, Turbo
,	0212010	(Incl. Rt & Lt)

### ♦ Note:

Parts not sold separately. Must be purchased as a complete unit.

### **OPTIONAL PARTS NOT ILLUSTRATED**

8212351 Hooks, Dough (Incl. Rt & Lt) 8212341 Rod, Blending 8212340 Whisk

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# KitchenAid® 3-SPEED HAND MIXER

**MODELS:** 


KHM3WH5 (White) 4KHM3WH5 (White)



FOR CUSTOMER SATISFACTION ALWAYS USE FACTORY SPECIFICATION PARTS



KITCHENAID




2

4176951

## **UNIT PARTS**

Variations of Models: KHM9\_\_5



## Wisconsister (Trilingual) 8212056 Repair Parts List Mixer, Complete 8212348 Beaters, Turbo (Incl. Rt & Lt) 8212351 Hooks, Dough (Incl. Rt & Lt) (Incl. Rt & Lt) 8212341 Rod, Blending 5 6 8212340 Whisk

### ♦ Note:

Parts not sold separately. Must be purchased as a complete unit.