



FoodSaver®

QuickStart

WineSaver

Features of Your FoodSaver Appliance



Questions? Visit us at www.foodsaver.com or call 1-800-777-5452 (U.S.) or 1-877-804-5383 (Canada).
Get tips on vacuum packaging and order FoodSaver accessories.

Features

Getting Started

How to Vacuum Package with the FoodSaver WineSaver



Place Bottle Stopper in Bottle



Insert Tip into Port



Press and Hold On Button

1. Always leave at least one inch of space between contents and rim.
2. Wipe rim of bottle to ensure it is clean and dry.
3. Place Bottle Stopper in bottle.
4. Place tip of Easy-glide Nozzle **(A)** into port on top of Bottle Stopper.
5. While holding the WineSaver Appliance in place, press and hold On Button **(B)**.
6. Wait until green Indicator Light **(C)** turns on before releasing the button and removing appliance from Bottle Stopper.
7. Store bottle upright. If stored on its side the vacuum may be lost.
8. For handy appliance storage, place in Countertop Stand **(D)**.

How to Open FoodSaver Bottle Stoppers

To release vacuum and open, simply twist and pull up on Bottle Stopper.

How to Use the WineSaver with other FoodSaver Accessories

The FoodSaver WineSaver can be used with all FoodSaver Accessories (including Vacuum Packaging Canisters, Quick Marinators, Universal Lids, and Jar

Sealers) by placing tip of Easy-glide Nozzle **(A)** directly into port on top of accessory. See instructions for each accessory for more detail.

Important Safeguards

For your own safety, always follow these basic precautions when using a FoodSaver Appliance:

1. Read QuickStart Guide carefully for operating instructions.
2. Do not use appliance on wet or hot surfaces, or near a heat source.
3. Do not immerse any part of appliance, power cord or plug in water or other liquid.
4. To disconnect, unplug power cord from electrical outlet. Do not disconnect by pulling on cord.
5. Do not operate appliance with a damaged power cord or plug. Do not operate appliance if it malfunctions or is in any way damaged. If cord or appliance is damaged, you can return it to an authorized service center for repair. For details, contact Consumer Services at number listed at bottom page.
6. Use appliance only for its intended use.
7. Close supervision is required when using any electrical appliance near children. Do not allow appliance to be used as a toy.
8. The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
9. 120v Appliances Only: The FoodSaver Appliance has a polarized plug (one blade is wider than the other). To reduce risk of electrical shock, this plug is intended to fit in a polarized outlet only one way. If plug does not fit fully in the outlet, reverse plug. If it still does not fit, contact a qualified electrician. Do not modify plug in any way.

For Household Use Only SAVE THESE INSTRUCTIONS

Care and Cleaning

The FoodSaver WineSaver Appliance

1. Always unplug appliance before cleaning.
2. Do not immerse appliance in water.
3. Avoid using abrasive products or materials to clean any appliance components. These cleaners can scratch the surface.
4. Use a mild dishwashing soap and a warm, damp cloth to wipe away food residue.
5. Dry thoroughly before reusing.

Troubleshooting

Nothing happens when I try to vacuum package:

1. Check power cord to see if it is firmly plugged into electrical outlet.
2. Examine power cord for any damage.

3. See if electrical outlet is operative by plugging in another appliance.
4. Wait 20 minutes to allow appliance to cool off, and then try using it again.

Note: The appliance will shut off automatically if it becomes too hot.

To keep your appliance from overheating: Do not operate for more than 4 minutes at a time. Wait at least 20 seconds for appliance to cool down before you begin vacuum packaging another item.

The FoodSaver Bottle Stopper will not vacuum:

1. Check Bottle Stopper to see if it fits snugly inside bottle. If it is loose, air may enter and prevent it from vacuuming properly.
2. Examine neck of bottle and tip of WineSaver Appliance for food materials. Any gap can prevent bottle from vacuuming properly.

Safeguards

Warranty and Service Information

At Tilia, Inc. ("Tilia"), the makers of FoodSaver, we stand behind our products. That's why we provide a warranty on FoodSaver Appliances, Accessories, and other products.

ONE-YEAR LIMITED WARRANTY

The following warranty policy applies only to the original consumer of this product and is not transferable. Evidence of original purchase is required for warranty service (this could be the sales receipt or packing slip, etc.).

What the Warranty Covers

Tilia warrants, for one year from the date of purchase, to the original consumer, the FoodSaver Appliance and associated FoodSaver products in this kit to be free from defects in materials and workmanship under intended home use, subject only to the limitations and exclusions set out below.

What the Warranty Does Not Cover

This warranty to the original consumer shall terminate and be of no further effect one year after the date of the original purchase or if you sell or otherwise transfer the product. This warranty is invalid if this product is:

- a. Used for commercial or rental purposes;
- b. Damaged due to careless or improper maintenance, misuse, abuse or operation not in accordance with the operating instructions as explained in the accompanying QuickStart Guide;
- c. Serviced or repaired by persons other than those authorized by Tilia, Inc.;
- d. Modified, aligned, altered or tampered with;
- e. Damaged due to natural disasters including but not limited to lightning or power surges; or
- f. Used in any conjunction with equipment or parts or as part of any system not manufactured by Tilia.

This limited warranty is the sole and entire warranty pertaining to the product and is in lieu of and excludes all other warranties of any nature whatsoever, whether express, implied or arising by operation of law, including, but not limited to, any implied warranties of merchantability or fitness for a particular purpose. This warranty does not cover or provide for the reimbursement or payment of incidental or consequential damages. This warranty is void outside

North America (the United States, its possessions, Canada and Mexico).

What Tilia Will Do to Correct Problems

In the event the product does not conform to this warranty at any time while this warranty is in effect, Tilia will repair or replace the product (at Tilia's option) and return it to you without charge for parts, services or any other cost (except shipping and handling) incurred by Tilia or its representative in connection with the performance of this warranty.

How State Law Relates to this Warranty

This warranty gives you specific legal rights, and you may also have other rights, which vary from state to state.

If Tilia cannot lawfully disclaim or exclude implied warranties under applicable law, then to the extent possible any claims under such implied warranties shall expire on expiration of the warranty period. Some states do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you. Some states do not allow the exclusion or limitation of incidental or consequential damages so the above limitation or exclusion may not apply to you.

How You Can Get Warranty Service

Before you return your product for warranty repair, call Tilia's Consumer Services Department listed below for complete shipping instructions and a Return Authorization (RA) number. Any product returned for warranty repair must be delivered freight prepaid in either its original packaging or packaging affording an equal degree of protection.

If You Need Service, Contact:

Tilia, Inc.

www.foodsaver.com
customerservice@foodsaver.com
P.O. Box 194530
San Francisco, CA 94119-4530

Toll-Free Consumer Services Support

United States: 1-800-777-5452
Canada: 1-877-804-5383

Evidence of original purchase is required, so **hold onto your sales receipt or packing slip.**