



Changing filter cartridge



The filter cartridge provides clean, clear and fresh water for perfect tasting espresso by reducing water impurities like chlorine. It also protects the espresso maker by reducing limescale build-up. When using the Krups filter cartridge, one descaling per year will be sufficient.

Descaling



The descaling frequency depends on the water hardness and frequency of use. Only use KRUPS descaling agent (art. no. F054)!

Maintenance

Clean the appliance regularly using mild, non-abrasive cleaning agents only



Accessories



Troubleshooting

Coffee is not hot enough	- Pre-heat cups with hot water
Espresso leaks around the filter holder	- Position filter holder correctly - Clean the filter holder - Recommend folding down the paper as well
Pump is very noisy	- Fill the water tank - Press firmly on the water tank
Water doesn't run through	- Fill water in the water tank and press firmly in place - Clean the filter and the grid on the head - Descal appliance
Water runs through too quickly	- Try a finer coffee - Fill with more grounds - Press down the coffee in the filter holder more firmly
The espresso has no crema (froth on coffee)	- Try a finer coffee - Use very fresh coffee - Press down the coffee in the filter holder more firmly
Lots of water on the coffee grounds	- Fill with more grounds
The milk is not very frothy	- Nozzle blocked? -> use a fine needle to unblock it - Use very cold and very fresh milk - Try a different brand of milk
Filter holder very difficult to adjust (1 or 2 cups)	- Phunge the total filter holder in hot water during 15 min.
Coffee quantity in cup is too small or too large	- Re-programm coffee quantity as described in Espresso section

LIMITED WARRANTY

This Krups product is warranted for 1 year from the date of purchase against defects in material and workmanship. During this period, the Krups product that, upon inspection by Krups, is proved defective, will be repaired or replaced, at Krups' option, without charge to the customer. If a replacement product is sent, it will carry the remaining warranty of the original product. This warranty does not apply to any defect arising from a buyer's or user's misuse of the product, negligence, failure to follow Krups' instructions, use on current or voltage other than that stamped on the product, wear and tear, alteration or repair not authorized by Krups, or use for commercial purposes.

THE WARRANTIES SET FORTH HEREIN ARE EXCLUSIVE AND NO OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE OR USE, ARE MADE BY KRUPS OR ARE AUTHORIZED TO BE MADE WITH RESPECT TO THE PRODUCT.

Some states do not allow limitation on how long an implied warranty lasts or do not allow the exclusion of incidental or consequential damages, so the above limitations may not apply to you. This warranty gives you specific legal rights, and you may also have other rights, which vary from state to state.

If you believe your product is defective, bring the product (or send it, postage prepaid) along with proof of purchase to the nearest authorized Krups Service Center. (Please contact your respective country's customer service department, indicated below, for the address of the nearest authorized Krups Service Center.)

If you send the product, please include a letter explaining the nature of the claimed defect.

If you have additional questions, please call our Consumer Service Department:

USA: 1-800-526-5377;
Mon - Fri 8:30 a.m. - 7:00 p.m. (EST).
www.KrupsUSA.com

Canada: 1-800-418-3325;
Mon - Fri 8:30 a.m. - 4:30 p.m. (EST)
www.Krups.ca

Please note hours are subject to change.

Before calling the Consumer Service Department, please have the type number of your Krups appliance available. This will assist in answering your questions. The type number is generally found on the bottom of the machine. It would be helpful if you had the appliance available at the time of your call.

General correspondence can be addressed to:

USA:
Krups
196 Boston Avenue
Medford, MA 02155

Only letters can be accepted at this address. Shipments and packages that do not have a return authorization number will be refused.

Canada:
Groupe SEB Canada Inc.
455 Finchdene Square
Scarborough, Ontario M1X 1B7

Operating manual

Please read the TSM Success Manual® before operating the appliance. In order to obtain beverages of good quality and to avoid damage or injury, follow the instructions precisely. Ensure that these instructions are given to any other users of the appliance and that they are kept in a safe place so that they can be referred to at any time. The appliance has been strictly checked for safety and correct operation. It left the factory in fault-free working order.

For domestic use only

The warranty does not include espresso machines which do not function, or do not function properly, because descaling has not been carried out.

Consumer Service USA 1-800-526-5377
Web site: www.KrupsUSA.com 1-800-418-3325
Web site: www.Krups.ca



XP 5080
Autocappuccino

KRUPS